**INSTALLATION GUIDE** 

### NON-DIMMING DRIVER W/JUNCTION BOX












# **PRE-INSTALLATION**

**Surface Mount** 

Power input is 100V - 277V AC. Confirm the source voltage is compatible.

Disconnect power source prior to installation.

#### **DIMENSIONS**



#### **SAFETY**

Read all instructions before installation.

These products may represent a possible shock or fire hazard if improperly installed.

**Do not** install less than 6 inches from a combustible material.

**Do not** install less than 5 feet above the ground.



Product should be installed by a qualified electrician.



Product should be installed in accordance with these instructions and current electrical codes.

# **INSTALLATION**

STEP 1

Mount the PSHK Series Driver to your chosen surface. It can be mounted vertically or horizontally.

\*Maintain a 2 minimum clearance around the driver to provide proper air circulation. (Figure 1)

STEP 2

Unscrew the two screws on the housing. Pull off the cover to expose the driver wires. (Figure 2)

STEP 3


Insert the 100-277V AC power into the driver housing from the electrical panel. Followed by bringing the 24V low voltage wires from the LEDs into the driver housing. (Figure 3)


\*See wiring guide on page 2.


STEP 4

Insert the nut connections in the driver housing and close the housing cover.

Secure the housing cover by tightening the two screws.









# **INSTALLATION** (CONT.)

### **WIRING GUIDE**

