# PSHW-35W-12V Hardwire Non-Dimming Constant Voltage Driver



# **SPECIFICATION SHEET**

JOB NAME:	
LOCATION:	
QUOTE/REF#:	

Hardwire LED drivers are commonly used for DC LED systems, typically with on/off switches or compatible RGB controllers. These 12V constant voltage drivers are the perfect match for 120V switches and RGB(W) and DMX controls. Available in a wide range of wattages and mulitple form factors. Use these LED drivers to meet your specific low-voltage lighting needs.

### **FEATURES**





- Class 2 power supply Universal AC Input / Full Range
- Free Air Convection Cooling
- Small Form Factor / Compact Size
- Short Circuit / Overload / Over Voltage Protection
- Suitable for Indoor / Outdoor Use

# INPUT SPECIFICATIONS

INPUT VOLTAGE RANGE	100V ~ 240V AC ± 6%
FREQUENCY RANGE	47 ~ 63 Hz
EFFICIENCY	84%
AC CURRENT	1.1A/115VAC   0.7A/230VAC
INRUSH CURRENT	COLD START 55A at 230VAC
LEAKAGE CURRENT	0.25mA / 240VAC

## **ENVIRONMENT**

WORKING TEMPERATURE	-30 ~ 70°C	
WORKING HUMIDITY	20~90% RH non-condensing	
STORAGE TEMPERATURE	-40~80°C	
HUMIDITY	10~95% RH	
TEMP COEFFICIENT	±0.03% °C (0~50°C)	
IP RATING	IP67	

# **OUTPUT SPECIFICATIONS**

OUTPUT VOLTAGE	24V
OUTPUT CURRENT	1.5A
CURRENT RANGE	0 ~ 1.5A
OUTPUT POWER	36W
RIPPLE & NOISE	120mVp-p
VOLTAGE TOLERANCE	± 5.0%
LINE REGULATION	± 1.0%
LOAD REGULATION	± 2.0%
SETUP, RISE TIME	500ms, 20ms/230VAC
	500ms, 20ms/115VAC at full load
HOLD UP TIME	50ms/230VAC
	16ms/115VAC at full load

# SAFETY SPECIFICATIONS

OVER LOAD	Hiccup Mode
OVER VOLTAGE	Shut Off o/p Voltage

# WIRING DIAGRAM
















### DIAGRAM AND DIMENSIONS



# **INSTALLATION GUIDE**



THIS TRANSFORMER IS ONLY TO BE INSTALLED BY A QUALIFIED TECHNICIAN IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRICAL CODES

# **BEFORE YOU BEGIN**

Make sure the transformer has the proper input voltage and wattage for the intended job. Check wiring and make sure they match the diagram on this guide.

# MOUNTING

Select a suitable and proper location to mount the driver. Consider the weight of the driver to be supported.


# INPUT CONNECTIONS / GROUNDING

- 1. Remove input wiring cover and install strain reliefs.
- 2. Make sure power is turned off. Route input wires and make connections based on wiring diagram following the INPUT side.
- 3.Make sure that driver is properly grounded in accordance with the N.E.C.

# **OUTPUT CONNECTIONS**

- 1. Remove output wiring cover and install clamp connectors.
- 2. Make sure power is turned off. Route fixture wires and make connections based on wiring diagram following the OUTPUT side.

# **DERATING CURVE**



AMBIENT TEMPERATURE (°C)